


## Instructions for use of remote control



## Warning

- Please avoid looking directly at the light.
- The disassembly process must be carried out in a safe place.
- Do not short circuit or disassemble: Do not put in water or near fire.
- Without expert guidance, it is forbidden to repair and dismantle lamps by yourself: The supplier is not responsible for any consequences caused by improper operation or improper maintenance by the user.

## User manual



## SOLAR STREET LIGHTS

Thank you for choosing our product.

- For any questions, free to call or email us any time.
- Please refer to the actual product If the diagrams provided shows a slight difference.
- Before using the product, please read the following precautions carefully to avoid damage or errors.

## Product Overview


Solar light is an electric lamp which converts light energy into electricity by solar panels. The advantage of the solar light is no wiring, easy to installation and without electricity. In the day time, solar panel absorbs the sun's light and convert to electricity and store in batteries. At night, the lamp will turn on automatically.

## Packing List

1.Lamp	2.Operating Manual
3.Screws	4.Hexagonal Screwdriver

## Installation Guide

Rated Power: LED 50W/100W/150W/200W/250W/300W  
 Lighting Mode: Time Control/Motion sensing/Light control  
 IP Rating: IP65



### Red/Blue LED Indications


LED Indication Condition

Red: ON	Charging during daytime
Red: OFF	No Charging while solar panel under dark environment
Blue: ON	Motion Sensing Mode, full brightness once sensing activated, otherwise 30% brightness
Blue: OFF	Constant Brightness Mode


## Installation Guide



1. Insert the lamp pole/arm into the lamp body and tighten the screw, lamp pole/arm diameter have to within 45-50mm as shown in the left picture below.



2. Please select the appropriate product according to the installation site's sunlight intensity and required operating time. If you are in the northern hemisphere, face the solar panels towards the south as far as possible when installing the solar light; if you are in the southern hemisphere, face the solar panels towards the north.



(A diagram for how the orientation impacts on power generation efficiency)